

Package Contents

- *Unpacking Instructions*
- Sil 4726 Storage Appliance
- Two-meter length external SATA cable
- AC power cord
- CD-ROM containing:
 - Sil 4726 Manager Software
 - *Quick Installation Guides*
 - *User's Guides*

If ANY of the contents are missing or appear damaged, please contact your dealer/distributor immediately.

Product Registration

Thank you for purchasing SteelVine products. Please register this product at www.steelvine.com/product_registration. Registering the product ensures the validity and terms of the warranty.

For environmental and regulatory information, please go to:
<http://www.siliconimage.com/products/product.aspx?id=47>


Copyright © 2005, Silicon Image, Inc. All rights reserved. No part of this publication may be reproduced, transmitted, transcribed, or translated into any language or computer format, in any form or by any means without prior written permission of:

Silicon Image, Inc.
1060 East Arques Ave.
Sunnyvale CA 94085

Silicon Image and the Silicon Image logo are the trademarks or registered trademarks of Silicon Image, Inc. ("Silicon Image") in the United States and other countries. The information contained in this document is provided by Silicon Image merely as a courtesy and is, to the knowledge of Silicon Image, accurate. However, Silicon Image is under no obligation to update and/or keep current the information contained in the document. Silicon Image disclaims any and all liability resulting from the use of the information contained in this document and any reliance on such information shall be at the sole risk of the relying party. Silicon Image expressly reserves the right to change the information contained herein without notice."

Document Number: DOC-004723-213

Revision: 1.0



Quick Installation Guide (Mac OS X)



Sil 4726 Installation

Introduction

The Sil 4726 Storage Appliance is a five-drive array that connects to the external SATA connector on your host computer.

Prerequisites

- Hardware**
 - Mac G4/G5 500MHz or faster
 - CD-ROM drive
 - 64 MB of RAM minimum
 - 250 MB of free hard disk space
 - Super VGA (800 x 600) or higher resolution with 256 colors
 - Mouse or compatible pointing device
 - External SATA cable connection between the Sil 4726 Storage Appliance and host computer
 - SteelVine Host Bus Adapter card, part number SV-HBA3124, or another SATA host controller with Port Multiplier (PM) support
- Software**
 - Mac OS X version 10.x with the latest set of patches installed
 - SV-HBA3124 CD
 - Sil 4726 CD

Procedure

1. Turn off your host computer.
2. Connect one end of the external SATA cable to the external SATA connector on your host computer. If needed, install the SV-HBA3124 card and driver (see the *SV-HBA3124 Quick Installation Guide*).
3. Connect the other end to the Sil 4726 Storage Appliance.
4. If hard disk drives are not installed in the appliance, insert the drives most of the way into each bay; flip out the drive carrier lever, gently insert the drive carrier until the drive is almost fully inserted, and push the lever shut to seat the drive securely.
5. Attach one end of the AC cable to the Sil 4726 Storage Appliance and the other end to the proper AC receptacle.
6. Turn on the Sil 4726 Storage Appliance.
7. Turn on the host computer.
8. Launch **Disk Utility** from the Application > Utilities folder to view the hard disk drives.
9. Verify an unpartitioned SteelVine disk is visible. Another “320.0 KB Config Disk Media” disk represents the Sil 4726 processor. Do not initialize or partition this Sil 4726 processor disk.
10. If you plan to use the currently defined configuration mode, format the unpartitioned disk so it is recognized as a volume. Otherwise, follow these steps to install the Sil 4726 Manager software:
 - Insert the Sil 4726 installation CD in the CD-ROM drive.
 - Open the installation CD and select the Mac folder.
 - Double-click the **Sil 4726 V<number>.pkg.zip** file.
 - Click **Continue** to dismiss the start screen.
 - Read the release-specific Read Me and click **Continue**.
 - Read the software license agreement and click **Continue**.
 - Click **Agree** to accept the license agreement.
 - Select the local hard disk drive and click **Continue**.
 - Click **Install** to install the Sil 4726 Manager into the /Applications/Utilities/Sil 4726 directory.
 - Click **Close** to conclude the installation.
 - Launch the Finder and locate the Sil 4726 Manager within the Applications > Utilities > Sil 4726 folder. Double-click the Sil 4726 icon to start the Sil 4726 Manager.
 - Follow the instructions in the *Sil 4726 User's Guide* to create logical volumes, select storage policies for the volumes, and partition the disks in the Mac OS X Disk Utility.